



Coördinaten (hart boring)

#	Naam	X	Y	Z
1	Inleidpunt	132 31.00	482 585.75	-0.06
2	Start neergaande bocht	132 306.11	482 622.28	-11.76
3	Start paalmatras	132 303.40	482 640.93	-13.05
4	Eind neergaande bocht	132 297.68	482 682.50	-21.5
5	Start horizontale bocht	132 291.82	482 725.01	-21.5
6	Eind hor. bocht/start opp. bocht	132 290.87	482 771.48	-21.5
7	Eind opgaande bocht	132 297.43	482 839.56	-5.44
8	Uitleidpunt	132 299.66	482 862.70	-0.98